

ES730 SLEEVE MAINTENANCE SYSTEM INFORMATION AND OPERATION

Patents:

USA - 11,255,192

Russia - 2788362

India - 202047044367

Australia - 2019237295

South Africa - 2020/05894



Queries?

Call/whatsapp 079 913 3123/084 510 9252 **E- mail –** info@phoenixeng.co.za



Easy Sleeve maintenance system components – ES730



Portable trolley:

All Easy sleeve components are attached to the trolley, keeping everything at hand and out of the dirt. Easy to pull along or 2 person carry

Part nr: 42077443



ES7300 hydraulic cylinder

Part nr: 42077419



ES7300 Sleeve installation cup (lolliepop) and installation horse shoe clip

42077451

Part nr: 42077447



P39 hand pump assembly

Part nr: 42077437



ES7300 Sleeve extraction cup

42077449 Part nr:



ES7300 Sleeve extraction horse shoe clip

42077445 Part nr:

Queries?

Call/whatsapp 079 913 3123/084 510 9252 E- mail - info@phoenixeng.co.za



Easy Sleeve maintenance system components – ES730



Part nr: 42077452

ES7300 Safety Cage:

Never apply pressure until the safety cage has been installed!!

Queries?

Call/whatsapp 079 913 3123/084 510 9252 **E- mail –** info@phoenixeng.co.za



Before using the Easy Sleeve maintenance system

- 1. Always ensure to adhere to your mines health, safety and operational procedures
- 2. Make your work area safe, identify and manage risks
- 3. Always inspect all hydraulic components before putting the system under pressure
- 4. If you are not sure about any operational process stop work and get help before using the system
- 5. The system uses hydraulic pressure to install and remove sleeves, always wear PPE and use Safety Cage when the system is being pressurized

Queries?



Always make sure the puller is properly lined up, all faces seat flush and blue always faces away from the hydraulic cylinder

INSTALATION




EXTRACTION





ES730 Installation



PRE-INSTALATION

- 1. Make sure the pick box/sleeve are clean, smooth and lubricated with grease
- 2. Make sure all contact areas are seated flat against each other
- 3. Always ensure all green and flat faces are facing away from the hydraulic cylinder

INSTALATION

- 1. Insert and seat the sleeve
- 2. Push the hydraulic cylinder shaft completely through the sleeve and pick box
- 3. Insert the installation cup and horse shoe clip at the back of the pick box, flat blue faces always facing away from hydraulic cylinder
- 4. Install safety cage before applying pressure

Queries?

Call/whatsapp 079 913 3123/084 510 9252 **E- mail –** info@phoenixeng.co.za 6



ES730 extraction

sequence

PRE-EXTRACTION

- 1. Make sure the sleeve is clean and clear of any obstructions
- 2. Make sure all contact areas are seated flat against each other
- 3. Always ensure all blue and flat faces are facing away from the hydraulic cylinder

EXTRACTION

- 1. Insert and seat the extraction cup on the hydraulic cylinder and the sleeve
- 2. Push the hydraulic cylinder shaft completely through the sleeve and pick box
- 3. Insert the extraction horse shoe clip at the back of the sleeve and pick box
- 4. Install safety cage before applying pressure

Queries?

Call/whatsapp 079 913 3123/084 510 9252 E- mail – info@phoenixeng.co.za

